



Section A2

This Price Schedule is effective March 1, 2025.

Telephone / Video Entry & Access Control Systems

Date	Page	Comment
3-1-25	All	March 2025 Price Schedule update.
3-10-25	30, 31	Updated 2112 part numbers and pricing.
3-21-25	30, 31	Corrected part number for 2112 surface mount curved model.
4-8-25	31	Updated 2108 part number.
4-9-25	31	Added 2112-581 and 2112-582 Upgrade Kits.
4-10-25	31	Added additional notes to upgrade kits.

Entry System Connection Options and Cloud Programming– Your Choice

DoorKing 1830 Series entry system connection options include the DoorKing Cloud as an added benefit at no additional cost. Using the DoorKing Cloud, you can program and manage your access system from any device (laptop, tablet, smartphone) with an internet connection – a dedicated PC is no longer needed. The DoorKing Cloud is included with Cellular, VoIP, DoIP and IM Server subscriptions.

For more information, please visit:

<https://www.doorking.com/easy-connect/programming/cloud>

4G-LTE Cellular Service (Plug & Play)

- Voice and Programming (wireless via the cellular network)
- DKS Cellular (subscription based service)

Internet (VoIP) Connection (Plug & Play)

- Voice and Programming (wired connection)
- DKS Internet or VoIP subscription service required
- Requires 1830-186 Network Adapter for programming¹
- Requires 1815-578 VoIP adapter for DKS VoIP¹ or use third party VoIP adapter²
- Plug & Play for LAN and WAN connections 2334-080^{3,4}

1: Subscription service.

2: DoorKing does not guarantee third party VoIP service. Third party VoIP subscription may be required.

3: Combines 1830-186, 1815-578 and Ethernet switch into a single enclosure.

4: IMPORTANT! When used with 1830 Series systems, the 1830 Series circuit board MUST be Revision Z or higher.

Internet (VoIP) Connection (Manual IP Configuration)

- Voice and Programming (wired connection)
- Manual setup – requires 1830-185 Network adapter
- Manual setup required: determine Default Gateway, set your IP address, setup Port Forwarding, configure Firewall for access, order Static IP address from internet provider or setup DDNS host account
- Compatible with most VoIP providers¹

1: DoorKing does not guarantee third party VoIP service. Third party VoIP subscription may be required.

Land Line Telephone Service³ (POTS line, Cable or Fiber¹)

- Voice and Programming (wired connection)
- Programming options:
 - IM Server Modem (subscription based service)
 - Modem to Modem²

1: Not applicable if Cable or Fiber is a cloud based telephone service.

2: Not compatible with all modems. Requires phone line and modem at programming PC.

3: DoorKing does not recommend using POTS (Plain Old Telephone Service) as a connection option and does not guarantee modem connections as many phone company services and switches no longer support modem communications.

TTY Connection Options

- Allows hearing impaired persons to connect their TTY device to the telephone entry system.
- P/N 1830-310 is factory installed at time of order.
- P/N 1830-315 is an add-on device that can be added to the telephone entry system at any time.

Table of Contents

Telephone Entry & Access Control

Model 1802	4
Model 1803	6
Model 1808	8
Model 1810	10
Model 1812	12
Model 1816	14
Model 1819	16
Model 1833	18
Model 1834	20
Model 1835	22
Model 1837	24
Model 1838	26
Model 1838 Access Plus	28
Model 2100 Series Video Entry Systems	30

Accessories

Connection Options.....	32
Elevator Control.....	33
Tracker Expansion Boards	34
Wireless Kits for Tracker Expansion Boards	35
Telephone Entry Systems Mounting Kits.....	36
Light Kits	37
Utility Enclosures	38
Accessories	40
Replacement Components	41

1802 Telephone Entry System


Residential, Commercial

1802 / 1802 EPD

- Hands free full duplex voice communication
- Programmable Directory Codes (1-4 digits)
- 16-digit dialing
- Includes 16 VAC power transformer
- Backlit keypad and A-Z-CALL buttons (EPD only)

1802 AP (Access Plus) ONLY

- Control up to 8 entry points
- IP Addressable
- PC Programmable
- 2-Digit directory codes
- 20-digit dialing
- Includes 16 VAC power transformer



Model	Phone Numbers	Directory ⁶ Names	Entry Codes ¹	Device Codes ²	Relays	Auxiliary Inputs ³	Expansion ⁴	Computer Programmable ⁵	Temporary Codes	Holiday Schedules
1802	600	N/A	1000	0	2	1	No	No	5	No
1802EPD	100	100	100	0	2	1	No	No	5	No
1802AP ⁷	27	N/A	0	100	2	2	6 Max	Yes	10	Yes

1. Entry codes are four (4) digits only and are not the same as device codes. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
2. Device codes refer to any five (5) digit RS-485 device used to access an entry point, such as cards, transmitters or PINs (Personal Identification Number). Five (5) digit device codes can also be used on the system keypad.
3. 1802 and 1802EPD, auxiliary input allows a switch closure to activate relay 2, or can be set to auto-dial a preprogrammed telephone number. 1802 AP uses a standard RS-485 data input.
4. Six (6) additional entry points can be controlled via RS-485 card readers, AVID tag readers, RF receivers or digital keypads.
5. AP Programming software available for free download at doorking.com.
6. Single line 16 character 5/16 LCD display.
7. Access Plus model does not have any programming display or electronic directory.

1802 Telephone Entry System**Residential, Commercial****1802 Telephone Entry Systems**

1802-082 Surface Mount	1602.00
1802-089 Flush Mount.....	2010.00
1802-090 Surface Mount EPD.....	1962.00
1802-091 Flush Mount EPD	2364.00
1802-092 Surface Mount AP (Access Plus).....	2508.00
1802-093 Flush Mount AP (Access Plus)	2544.00

Service Connection Options

1800-081 Cellular Voice + Data ^{1,2}	1822.00
1800-080 Cellular Voice + Data ^{1,3}	1822.00
1815-578 VoIP Adapter ⁴	200.00

1 - Cellular service plan required. See Section D1.

2 - Use with 1802 AP models.

3 - Use with 1802 and 1802 EPD models.

4 - DKS VoIP subscription required. See Section D1.

1802 Lobby Panels

1802-083 Surface Mount	1194.00
1802-094 Flush Mount.....	1598.00

Lobby panels can only be used with the 1816 or 1820 telephone intercom system. They cannot be connected directly to telephone service.

Accessories

1506-081 Secondary Keypad surface mount	596.00
1506-091 Secondary Keypad flush mount	1028.00
1804-193 External Speaker	570.00
1801-008 Backup Battery 12-Volt .8 Ah	124.00
2600-588 Heater Kit (1802, 1802 AP).....	364.00
2600-582 LCD Heater (1802 EPD)	88.58
1812-145 CCTV Color Camera	1374.00
1807-012 Handset Kit (surface mount only).....	566.00
1802-111 Post Mount Adapter Plate ¹	222.00

1. Required if mounting 1802 to gooseneck post.

1830-310 TTY Add-on Factory Installed	420.00
1830-315 TTY Add-on Kit	468.00

1802 AP (ACCESS PLUS ONLY) Expansion Options

2354-010 Conversion Board	244.00
1815-235 Conversion Board w/Enclosure	542.00
<i>Converts 26-bit Wiegand to RS-485. Requires 12-16 VDC power.</i>	

1812-018 12-VDC, 1A Transformer	65.92
1200-080 Transformer Box	314.00

1816-083 Intercom Phone Expansion	1534.00
---	---------

The 1816-083 expands the "No Phone Line" telephone intercom interface on Access Plus systems from a single phone line up to 11 phone lines. The system can be further expanded to interface with up to a maximum of 23 phone lines.

RS-485 Card Readers (ACCESS PLUS ONLY)

1815-337 DK ProxPlus Secure	614.00
1815-332 DK Prox Reader	596.00
1815-232 ID Tech Reader	678.00
1815-233 AWID Reader.....	710.00
1815-234 HID Reader	1230.00

RS-485 Keypads (ACCESS PLUS ONLY)

1513-081 Surface Mount	730.00
1513-082 Flush Mount.....	904.00

RS-485 RF Controls (ACCESS PLUS ONLY)


8053-080 MicroPlus Receiver.....	290.00
----------------------------------	--------

1803 Telephone Entry System


Residential, Commercial

1803

- Hands free full duplex voice communication
- Programmable Directory Codes (1-4 digits)
- 16-digit dialing
- Includes 16 VAC power transformer
- Stainless steel faceplate
- Galvanized steel sub-plate
- Metal keypads and buttons
- Postal lock provision



Surface Mount



Flush Mount

Model	Phone Numbers	Directory Names	Entry Codes ¹	Device Codes ²	Relays	Auxiliary Inputs ³	Expansion	Computer Programmable	Temporary Codes	Holiday Schedules
1803	600	N/A	1000	0	2	1	No	No	5	No

1. Entry codes are four (4) digits only and are not the same as device codes. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
2. Device codes are not used with the 1803.
3. 1803 auxiliary input allows a switch closure to activate relay 2, or can be set to auto-dial a preprogrammed telephone number.

1803 Telephone Entry System**Residential, Commercial****1803 Telephone Entry Systems**

1803-080 Surface Mount	2100.00
1803-084 Flush Mount.....	2100.00

1803 Lobby Panels

1803-090 Surface Mount	1398.00
1803-092 Flush Mount.....	1398.00

Lobby panels can only be used with the 1816 or 1820 telephone intercom system. They cannot be connected directly to telephone service.

Service Connection Options

1800-080 Cellular Voice + Data ¹	1822.00
1815-578 VoIP Adapter ²	200.00

1 - Cellular service plan required. See Section D1.

2 - DKS VoIP subscription required. See Section D1.

Mounting Accessories

1803-150 Surface Mount Recess Kit.....	430.00
1814-165 Flush Mount Kit Stainless Steel	738.00

Accessories

1506-081 Secondary Keypad surface mount.....	596.00
1506-091 Secondary Keypad flush mount.....	1028.00
1720-080 LED Light Kit	596.00
1804-193 External Speaker	570.00
1801-008 Backup Battery 12-Volt .8 Ah	124.00
2600-584 Heater Kit	226.00
1812-145 CCTV Color Camera	1374.00
1807-012 Handset Kit (<i>surface mount only</i>)	566.00

1830-310 TTY Add-on Factory Installed	420.00
1830-315 TTY Add-on Kit.....	468.00

1808 Telephone Entry System


Residential, Commercial

1808


- Hands free full duplex voice communication
- Programmable Directory Codes (1-4 digits)
- 16-digit dialing
- Includes 16 VAC power transformer

1808 AP (Access Plus) ONLY

- Control up to 8 entry points
- IP Addressable
- PC Programmable
- 2-Digit directory codes
- 20-digit dialing
- Includes 16 VAC power transformer



**Surface Mount
1808**



**Surface Mount w/Directory
1808 / 1808 AP**

Model	Phone Numbers	Directory ⁶ Names	Entry Codes ¹	Device Codes ²	Relays	Auxiliary Inputs ³	Expansion ⁴	Computer Programmable ⁵	Temporary Codes	Holiday Schedules
1808	600	N/A	1000	0	2	1	No	No	5	No
1808AP ⁷	27	N/A	0	100	2	2	6 Max	Yes	10	Yes

1. Entry codes are four (4) digits only and are not the same as device codes. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
2. Device codes refer to any five (5) digit RS-485 device used to access an entry point, such as cards, transmitters or PINs (Personal Identification Number). Five (5) digit device codes can also be used on the system keypad.
3. 1808 auxiliary input allows a switch closure to activate relay 2, or can be set to auto-dial a preprogrammed telephone number. 1808 AP uses a standard RS-485 data input.
4. Six (6) additional entry points can be controlled via RS-485 card readers, AVID tag readers, RF receivers or digital keypads.
5. AP Programming software available for free download at doorking.com.
6. Paper directory.
7. Directory can be printed from Access Plus programming software.

1808 Telephone Entry System**Residential, Commercial****1808 Telephone Entry Systems**

1808-082 Surface Mount w/Directory	2100.00
1808-084 Surface Mount	1962.00
1808-085 Surface Mount AP (Access Plus).....	2508.00

1808 Lobby Panels

1808-081 Surface Mount	1362.00
1808-083 Surface Mount w/Directory	1490.00

Lobby panels can only be used with the 1816 or 1820 telephone intercom system. They cannot be connected directly to telephone service.

Service Connection Options

1800-081 Cellular Voice + Data ^{1,2}	1822.00
1800-080 Cellular Voice + Data ^{1,3}	1822.00
1815-578 VoIP Adapter ⁴	200.00

1 - Cellular service plan required. See Section D1.

2 - Use with 1802 AP models.

3 - Use with 1802 and 1802 EPD models.

4 - DKS VoIP subscription required. See Section D1.

Accessories

1506-081 Secondary Keypad surface mount	596.00
1506-091 Secondary Keypad flush mount	1028.00
1804-193 External Speaker	570.00
1801-008 Backup Battery 12-Volt .8 Ah	124.00
1812-145 CCTV Color Camera	1374.00

1830-310 TTY Add-on Factory Installed	420.00
1830-315 TTY Add-on Kit	468.00

1808 AP (ACCESS PLUS ONLY) Expansion Options

2354-010 Conversion Board	244.00
1815-235 Conversion Board w/Enclosure	542.00

Converts 26-bit Wiegand to RS-485. Requires 12-16 VDC power.

1812-018 12-VDC, 1A Transformer	65.92
1200-080 Transformer Box	314.00

1816-083 Intercom Phone Expansion	1534.00
---	---------

The 1816-083 expands the "No Phone Line" telephone intercom interface on Access Plus systems from a single phone line up to 11 phone lines. The system can be further expanded to interface with up to a maximum of 23 phone lines.

RS-485 Card Readers (ACCESS PLUS ONLY)

1815-337 DK ProxPlus Secure	614.00
1815-332 DK Prox Reader	596.00
1815-232 ID Tech Reader	678.00
1815-233 AWID Reader	710.00
1815-234 HID Reader	1230.00

RS-485 Keypads (ACCESS PLUS ONLY)

1513-081 Surface Mount	730.00
1513-082 Flush Mount	904.00

RS-485 RF Controls (ACCESS PLUS ONLY)

8053-080 MicroPlus Receiver	290.00
-----------------------------------	--------

1810 Telephone Entry System


Residential, Commercial

1810


- Hands free full duplex voice communication
- Programmable Directory Codes (1-4 digits)
- 16-digit dialing
- Includes 16 VAC power transformer

1810 AP (Access Plus) ONLY

- Control up to 8 entry points
- IP Addressable
- PC Programmable
- 2-Digit directory codes
- 20-digit dialing
- Includes 16 VAC power transformer



Surface Mount
1810 / 1810 AP



Flush Mount
1810 / 1810 AP

Model	Phone Numbers	Directory ⁶ Names	Entry Codes ¹	Device Codes ²	Relays	Auxiliary Inputs ³	Expansion ⁴	Computer Programmable ⁵	Temporary Codes	Holiday Schedules
1810	600	N/A	1000	0	2	1	No	No	5	No
1810AP ⁷	27	N/A	0	100	2	2	6 Max	Yes	10	Yes

1. Entry codes are four (4) digits only and are not the same as device codes. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
2. Device codes refer to any five (5) digit RS-485 device used to access an entry point, such as cards, transmitters or PINs (Personal Identification Number). Five (5) digit device codes can also be used on the system keypad.
3. 1810 auxiliary input allows a switch closure to activate relay 2, or can be set to auto-dial a preprogrammed telephone number. 1810 AP uses a standard RS-485 data input.
4. Six (6) additional entry points can be controlled via RS-485 card readers, AVID tag readers, RF receivers or digital keypads.
5. AP Programming software available for free download at doorking.com.
6. Paper directory.
7. Access Plus model does not have any programming display. Directory can be printed from Access Plus programming software.

1810 Telephone Entry System**Residential, Commercial****1810 Telephone Entry Systems**

1810-080 Surface Mount	2038.00
1810-084 Flush Mount.....	2038.00
1810-095 Surface Mount AP (Access Plus).....	2668.00
1810-096 Flush Mount AP (Access Plus)	2668.00

1810 Lobby Panels

1810-088 Surface Mount	1580.00
1810-090 Flush Mount.....	1580.00

Lobby panels can only be used with the 1816 or 1820 telephone intercom system. They cannot be connected directly to telephone service.

Service Connection Options

1800-081 Cellular Voice + Data ^{1,2}	1822.00
1800-080 Cellular Voice + Data ^{1,3}	1822.00
1815-578 VoIP Adapter ⁴	200.00

1 - Cellular service plan required. See Section D1.

2 - Use with 1802 AP models.

3 - Use with 1802 and 1802 EPD models.

4 - DKS VoIP subscription required. See Section D1.

Accessories

1803-150 Surface Mount Recess Kit	430.00
1814-165 Flush Mount Kit Stainless Steel	738.00
1814-152 Surface Mount Ring for Flush Units	316.00

Accessories

1506-081 Secondary Keypad surface mount	596.00
1506-091 Secondary Keypad flush mount	1028.00
1720-080 LED Light Kit.....	596.00
1804-193 External Speaker	570.00
1801-008 Backup Battery 12-Volt .8 Ah.....	124.00
2600-584 Heater Kit.....	226.00
1812-145 CCTV Color Camera.....	1374.00
1807-012 Handset Kit (surface mount only).....	566.00

1830-310 TTY Add-on Factory Installed	420.00
---	--------

1810 AP (ACCESS PLUS ONLY) Expansion Options

2354-010 Conversion Board	244.00
1815-235 Conversion Board w/Enclosure	542.00
<i>Converts 26-bit Wiegand to RS-485. Requires 12-16 VDC power.</i>	

1812-018 12-VDC, 1A Transformer	65.92
1200-080 Transformer Box	314.00

1816-083 Intercom Phone Expansion	1534.00
---	---------

The 1816-083 expands the "No Phone Line" telephone intercom interface on Access Plus systems from a single phone line up to 11 phone lines. The system can be further expanded to interface with up to a maximum of 23 phone lines.

RS-485 Card Readers (ACCESS PLUS ONLY)

1815-337 DK ProxPlus Secure	614.00
1815-332 DK Prox Reader	596.00
1815-232 ID Tech Reader	678.00
1815-233 AWID Reader.....	710.00
1815-234 HID Reader	1230.00

RS-485 Keypads (ACCESS PLUS ONLY)

1513-081 Surface Mount	730.00
1513-082 Flush Mount.....	904.00

RS-485 RF Controls (ACCESS PLUS ONLY)

8053-080 MicroPlus Receiver.....	290.00
----------------------------------	--------

1812 Telephone Entry Systems


Residential

1812 (Classic)

- 2-Digit directory codes
- 11-digit dialing
- Includes 24 VAC transformer
- Call Forward Time Zones
- Do Not Disturb
- Analog Voice Circuit

1812 P and 1812 AP

- 2-Digit directory codes
- 20-digit dialing
- Includes 16 VAC transformer
- Call Forward Time Zones
- Do Not Disturb Feature
- HD Digital Voice Circuit



Model	Phone Numbers	Directory Names	Entry Codes ^{1,6}	Device Codes ²	Relays	Auxiliary Inputs ³	Expansion ⁴	Computer Programmable ⁵	Temporary Codes	Holiday Schedules
1812	3	N/A	25 / 25	0	2	0	No	No	5	No
1812P	27	N/A	0	50	2	0	No	No	10	No
1812AP	27	N/A	0	50	2	2	6	Yes	10	Yes

- Entry codes are four (4) digits on the 1812. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
- Device codes refer to any five (5) digit RS-485 device used to access an entry point, such as cards, transmitters or PINs (Personal Identification Number). Five (5) digit device codes can also be used as entry codes and are used on the system keypad.
- 1812 AP uses a standard RS-485 data input.
- Six (6) additional entry points can be controlled via RS-485 card readers, AVID tag readers, RF receivers or digital keypads.
- Access Plus Programming software available for free download at doorking.com.
- Each relay can be programmed with 25 entry codes with specific functions (see the installation manual 1812-065 for detailed information).
 - 14 momentary activation codes
 - 1 flash code
 - 5 hold codes
 - 5 time zone codes

1812 Telephone Entry Systems

Residential

1812 Classic Systems

1812-081 Surface Mount	1982.00
1812-097 Surface Mount w/Camera.....	3144.00
1812-087 Flush Mount.....	2240.00

1812 Plus Systems

1812-095 Surface Mount Curved	3036.00
1812-089 Surface Mount	2762.00
1812-098 Surface Mount w/Camera.....	3922.00
1812-091 Flush Mount.....	3024.00

Service Connection Options

1800-081 Cellular Voice + Data ^{1,2}	1822.00
1800-080 Cellular Voice + Data ^{1,3}	1822.00
1815-578 VoIP Adapter ⁴	200.00

1 - Cellular service plan required. See Section D1.

2 - Use with 1802 AP models.

3 - Use with 1802 and 1802 EPD models.

4 - DKS VoIP subscription required. See Section D1.

Accessories

1812-105 Stainless Steel Surface Mount Housing ¹	622.00
1506-081 Secondary Keypad surface mount	596.00
1506-091 Secondary Keypad flush mount	1028.00
2600-588 Heater Kit (for surface mount units)	364.00
2600-582 Heater Kit (for flush mount units)	88.58
1830-310 TTY Add-on Factory Installed	420.00
1830-315 TTY Add-on Kit	468.00
1812-145 CCTV Color Camera (use w/ 088, 093, 094)	1374.00
1812-147 CCTV Color Camera.....	1374.00
1812-074 Conversion Kit ³	2380.00

1 - Replaces the black steel housing.

2 - Secondary keypad not available on Plus models.

3 - Upgrades older 1812 units to an 1812 Access Plus unit.

1812 Access Plus Systems

1812-096 Surface Mount Curved	3170.00
1812-090 Surface Mount	2900.00
1812-099 Surface Mount w/Camera.....	4062.00
1812-092 Flush Mount.....	3158.00

1812 Access Plus Expansion Options

2354-010 Conversion Board	244.00
1815-235 Conversion Board w/Enclosure	542.00

Converts 26-bit Wiegand to RS-485. Requires 12-16 VDC power.

1812-018 12-VDC, 1A Transformer	65.92
1200-080 Transformer Box	314.00

1816-083 Intercom Phone Expansion	1534.00
---	---------

The 1816-083 expands the "No Phone Line" telephone intercom interface on Access Plus systems from a single phone line up to 11 phone lines. The system can be further expanded to interface with up to a maximum of 23 phone lines.

RS-485 Card Readers (ACCESS PLUS ONLY)

1815-337 DK ProxPlus Secure	614.00
1815-332 DK Prox Reader	596.00
1815-232 ID Tech Reader	678.00
1815-233 AWID Reader.....	710.00
1815-234 HID Reader	1230.00

RS-485 Keypads (ACCESS PLUS ONLY)

1513-081 Surface Mount	730.00
1513-082 Flush Mount.....	904.00

RS-485 RF Controls (ACCESS PLUS ONLY)


8053-080 MicroPlus Receiver.....	290.00
----------------------------------	--------

1816 Telephone Intercom Systems

Commercial

1816

- Full duplex voice communication
- Interfaces with up to 1200 phone lines
- Tennant C.O. phone service not required
- Programmable directory codes
- Lobby panel / Doorman caller ID
- Built-in call waiting
- Do Not Disturb feature



Model	Phone Numbers	Directory Names	Entry Codes ¹	Caller ID	Relays	Doorman Phone	Resident Features ²	Call Out Numbers	Directory Codes
1816	1200	N/A	1200	Yes	1	Yes	No	10	Programmable

- Entry codes are four (4) digits. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
- Resident programmable features include: Call Waiting; Do-Not-Disturb; Call Forwarding.

1816 Telephone Intercom Systems

Commercial

1816 Systems

Step 1: Main Control Cabinet

1816-080 Houses 13 Relay Boards (156 lines) 2968.00

1816-082 Houses 5 Relay Boards (60 lines) 2624.00

Main control cabinets do not include relay boards.

Step 2: Relay Boards

1982-010

1 – 13 Boards 956.00

14 – 29 Boards 916.00

30 + Boards 876.00

One (1) relay board is required for every 12 phone lines to be interfaced.

Step 3: Decoder Board (if required)

1881-010 Decoder Board 434.00

Decoder board(s) are required if the system expands beyond five (5) relay boards. One (1) decoder board is required for every eight (8) relay boards beyond the first five (5) relay boards.

Step 4: Auxiliary Cabinet (if required)

1816-081 Auxiliary Cabinet 876.00

Holds up to 16 relay boards and two (2) decoder boards.

Step 5: Phone Blocks and Cables

2370-010 RJ71C Phone Block 382.00

One (1) RJ71C is required for each relay board in the system.

1882-042 Connecting Cable 220.00

One (1) connecting cable is required for each relay board in the system.

1882-044 Connecting Cable Special Length 6.96 / ft.

Add cost per foot to 1882-042.

Step 6: Lobby Panels


Select lobby panels from the 1802, 1803, 1808, 1810 series pages.

1819 Information Telephone System

Commercial

1819

- Full duplex voice communication
- Stores a single phone number
- 10 and 11 digit dialing
- Call button



Surface Mount

Model	Phone Numbers	Directory	Entry Codes	Device Codes	Relays	Auxiliary Inputs	Expansion ⁴	PC Programmable	Elevator Control	Transaction Buffer
1819	1	N/A	0	0	1	0	0	No	No	No

1. The 1819 is designed as an information phone only. Pressing the CALL button causes the system to dial to a preprogrammed telephone number.

1819 Information Telephone System

Commercial

1819 Telephone Entry System

1819-080 Surface Mount 1854.00

Service Connection Options

1800-080 Cellular Voice + Data¹ 1822.00

1815-578 VoIP Adapter² 200.00

1 - Cellular service plan required. See Section D1.

2 - DKS VoIP subscription required. See Section D1.

Accessories

1801-008 Backup Battery 12-Volt .8 Ah 124.00

2600-588 Heater Kit..... 364.00

1802-111 Post Mount Adapter Plate¹ 222.00


1 - Required if mounting the unit to a goose neck post.

1833 Telephone Entry / Access Control System


Residential, Commercial

1833

- Full duplex voice communication
- Stores up to 3000 phone numbers
- 255 area codes
- Programmable directory codes
- 10 and 11 digit dialing
- Built-in clock/calendar
- Three (3) built-in relays
- Two (2) 26-bit wiegand inputs
- Expandable to control up to 24 entrances
- 31 security (permission) levels
- 32 holiday schedules
- True anti-pass back features



80 Series - Surface Mount



80 Series - Flush Mount

Model	Phone Numbers	Directory	Entry Codes ¹	Device Codes ²	Relays	Auxiliary Inputs ³	Expansion ⁴	DKS Cloud Programming ⁵	Elevator Control	Transaction Buffer
1833	3000	N/A	3000	8000	3	2	48 Max	Yes	Yes	8000

1. Entry codes are four (4) digits only and are not the same as device codes. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
2. Device codes refer to any five (5) digit 26-bit wiegand device used to access an entry point, such as cards, transmitters or PINs (Personal Identification Number). Five (5) digit device codes can also be used on the system keypad.
3. 1833 has two 26-bit wiegand inputs.
4. Up to 48 additional entry points can be controlled via card readers, AVID tag readers, RF receivers or digital keypads using wired tracker expansion boards. This is reduced to 24 if using wireless expansion.
5. DKS Cloud is included with connection service subscription plans. Programming with a dedicated PC is available using the Remote Account Manager software - available for free download at doorking.com.

1833 Telephone Entry / Access Control System**Residential, Commercial****1833 Telephone Entry / Access Control System**

1833-080 80 Series Surface Mount	4350.00
1833-084 80 Series Flush Mount.....	4350.00

Service Connection Options

1800-080 Cellular Voice + Data ¹	1822.00
2334-080 VoIP – TCP/IP Control Box ^{3,5}	848.00
1815-578 VoIP Adapter ^{2,4}	200.00
1830-186 Plug & Play ^{3,4} (Plug & Play)	306.00
1830-185 Network Adapter (Manual Setup)	306.00
<i>1 – DKS Cellular subscription required. See Section D1.</i>	
<i>2 – DKS VoIP subscription required. See Section D1.</i>	
<i>3 – DKS VoIP or Data over IP subscription required. See Section D1.</i>	
<i>4 – 1815-578 is required for voice, 1830-186 or 1830-185 is required for data</i>	
<i>5 – Combines the 1815-578 and 1830-186 into a common housing with built-in ethernet switch.</i>	

80 Series Mounting Accessories

1803-150 Surface Mount Recess Kit	430.00
1814-165 Flush Mount Kit Stainless Steel	738.00
1814-152 Surface Mount Ring for Flush Units	316.00

Accessories

1506-081 Secondary Keypad surface mount.....	596.00
1506-091 Secondary Keypad flush mount.....	1028.00
1720-080 LED Light Kit	596.00
1804-193 External Speaker	570.00
1801-008 Backup Battery 12-Volt .8 Ah	124.00
2600-584 Heater Kit	226.00
1812-145 CCTV Color Camera	1374.00
1812-147 Camera (use with surface mount only).....	1374.00
1807-012 Handset Kit (surface mount only)	566.00
1830-310 TTY Add-on Factory Installed	420.00
1830-315 TTY Add-on Kit	468.00

Expansion Options

2358-010 Tracker Expansion Board.....	690.00
2351-080 Sgl Box ¹ (1 board max)	936.00
2351-085 Sgl Box ¹ + 1470-080 900 MHz RF Module ..	1364.00
2351-082 QUAD Box ¹ Pre-wired (4 boards max)	1782.00
<i>1 – Includes one (1) 2358-010 board and 16V, 40 VA transformer.</i>	

Expansion Option Wireless Kits

2333-080 Base Board Kit ¹ 900 MHz.....	834.00
1470-080 Expansion Board Kit ² 900 MHz.....	494.00
2332-080 Dual channel repeater 900 MHz	774.00
<i>1 - One (1) base board kit is installed in the 1833 controller.</i>	
<i>2 – Expansion board kit(s) are installed on each 2358 tracker board.</i>	

1514-079 900 MHz antenna extension kit	80.72
8064-046 Coax cable extension 13-ft (3.9m)	70.22
1514-028 Disk antenna 900 MHz	45.06
1514-019 Six inch (152mm) antenna 900 MHz	45.06
1514-140 Wireless range test kit 900 MHz	1058.00

Elevator Control

2348-040 ¹ Elevator control board + hardware.....	2968.00
2348-080 ² Lockable enclosure	3846.00
2348-081 ³ Lockable enclosure large	4198.00
<i>1 – Includes board and mounting hardware.</i>	
<i>2 – Includes one (1) 2348-010 board. Room for two (2) boards' total.</i>	
<i>3 – Includes one (1) 2340-010 board. Room for four (4) boards' total.</i>	

1834 Telephone Entry / Access Control System


Residential, Commercial

1834 80 Series


- Separate surface and flush mount designs
- Surface mount includes black hood
- Optional surface mount trim ring
- Optional stainless steel flush mount kit
- Optional stainless steel wall mount trim ring for flush units

1834 90 Series


- Larger cabinet
- One design for surface, flush or wall mounting
- Dual locks, double weather seal
- Space for card reader¹, IP camera, TCP-IP adapter
- Optional 10 ga. hood, stainless steel or black
- Optional stainless steel flush mount kit



80 Series - Surface Mount



80 Series - Flush Mount



90 Series - Surface, Flush or Wall Mount

Model ¹	Phone Numbers	Directory	Entry Codes ²	Device Codes ³	Relays	Auxiliary Inputs ⁴	Expansion	DKS Cloud Programming ⁵	Elevator Control	Transaction Buffer
1834	3000	1-Line Electronic	3000	0	2	0	No	Yes	No	8000

1. 90 Series internal card reader mounting will accommodate the following card readers only: 1815-302 (DK Prox), 1815-380 (HID), 1815-215 (ID-Teck). Note that the 1834 does not have inputs for the card reader. Any card reader installed in the 1834 will have to be connected to another access controller. See 1835 if a built-in card reader is desired.
2. Entry codes are four (4) digits only and are not the same as device codes. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
3. Device codes refer to any five (5) digit 26-bit wiegand device used to access an entry point, such as cards, transmitters or PINs (Personal Identification Number). Five (5) digit device codes can also be used on the system keypad.
4. 1834 does not have any 26-bit wiegand inputs.
5. DKS Cloud is included with connection service subscription plans. Programming with a dedicated PC is available using the Remote Account Manager software - available for free download at doorking.com.

1834 Telephone Entry / Access Control System**Residential, Commercial****1834 Telephone Entry / Access Control System**

1834-080 80 Series Surface Mount.....	3640.00
1834-084 80 Series Flush Mount	3640.00
1834-090 90 Series Surface, Flush or Wall Mount	3640.00

Service Connection Options

1800-080 Cellular Voice + Data ¹	1822.00
2334-080 VoIP – TCP/IP Control Box ^{3,5}	848.00
1815-578 VoIP Adapter ^{2,4}	200.00
1830-186 Plug & Play ^{3,4} (Plug & Play).....	306.00
1830-185 Network Adapter (Manual Setup).....	306.00
<i>1 – DKS Cellular subscription required. See Section D1.</i>	
<i>2 – DKS VoIP subscription required. See Section D1.</i>	
<i>3 – DKS VoIP or Data over IP subscription required. See Section D1.</i>	
<i>4 – 1815-578 is required for voice, 1830-186 or 1830-185 is required for data</i>	
<i>5 – Combines the 1815-578 and 1830-186 into a common housing with built-in ethernet switch.</i>	

80 Series Mounting Accessories

1803-150 Surface Mount Recess Kit	430.00
1814-165 Flush Mount Kit Stainless Steel	738.00
1814-152 Surface Mount Ring for Flush Units	316.00

90 Series Mounting Accessories

1814-180 Stainless Steel Hood (10 ga) ¹	580.00
1814-185 Black Hood (10 ga)	286.00
1814-200 Flush Kit (Rough-in box + trim ring)	842.00
<i>1 – Recommended for corrosive environments such as coastal areas.</i>	

Accessories

1506-081 Secondary Keypad surface mount	596.00
1506-091 Secondary Keypad flush mount	1028.00
1720-080 LED Light Kit.....	596.00
1804-193 External Speaker	570.00
1801-008 Backup Battery 12-Volt .8 Ah	124.00
2600-584 Heater Kit.....	226.00
1812-145 CCTV Color Camera.....	1374.00
1807-012 Handset Kit (surface mount only).....	566.00
1830-310 TTY Add-on Factory Installed	420.00
1830-315 TTY Add-on Kit	468.00

1835 Telephone Entry / Access Control System


Residential, Commercial

1835 80 Series


- Separate surface and flush mount designs
- Surface mount includes black hood
- Optional surface mount trim ring
- Optional stainless steel flush mount kit
- Optional stainless steel wall mount trim ring for flush units

1835 90 Series


- Larger cabinet
- One design for surface, flush or wall mounting
- Dual locks, double weather seal
- Space for card reader, IP camera, TCP-IP adapter
- Optional 10 ga. hood, stainless steel or black
- Optional stainless steel flush mount kit



80 Series - Surface Mount



80 Series - Flush Mount



90 Series - Surface, Flush or Wall Mount

Model ¹	Phone Numbers	Directory	Entry Codes ²	Device Codes ³	Relays	Auxiliary Inputs ⁴	Expansion ⁵	DKS Cloud Programming ⁶	Elevator Control	Transaction Buffer
1835	3000	1-Line Electronic	3000	8000	3	2	48 Max	Yes	Yes	8000

1. 90 Series internal card reader mounting will accommodate the following card readers only: 1815-302 (DK Prox), 1815-380 (HID), 1815-215 (ID-Teck).
2. Entry codes are four (4) digits only and are not the same as device codes. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
3. Device codes refer to any five (5) digit 26-bit wiegand device used to access an entry point, such as cards, transmitters or PINs (Personal Identification Number). Five (5) digit device codes can also be used on the system keypad.
4. 1835 has two 26-bit wiegand inputs.
5. Up to 48 additional entry points can be controlled via card readers, AVID tag readers, RF receivers or digital keypads using wired tracker expansion boards. This is reduced to 24 if using wireless expansion.
6. DKS Cloud is included with connection service subscription plans. Programming with a dedicated PC is available using the Remote Account Manager software - available for free download at doorking.com.

1835 Telephone Entry / Access Control System**Residential, Commercial****1835 Telephone Entry / Access Control System**

1835-080 80 Series Surface Mount	5340.00
1835-084 80 Series Flush Mount.....	5340.00
1835-090 90 Series Surface, Flush or Wall Mount	5340.00

Service Connection Options

1800-080 Cellular Voice + Data ¹	1822.00
2334-080 VoIP – TCP/IP Control Box ^{3,5}	848.00
1815-578 VoIP Adapter ^{2,4}	200.00
1830-186 Plug & Play ^{3,4} (Plug & Play)	306.00
1830-185 Network Adapter (Manual Setup)	306.00
<i>1 – DKS Cellular subscription required. See Section D1.</i>	
<i>2 – DKS VoIP subscription required. See Section D1.</i>	
<i>3 – DKS VoIP or Data over IP subscription required. See Section D1.</i>	
<i>4 – 1815-578 is required for voice, 1830-186 or 1830-185 is required for data</i>	
<i>5 – Combines the 1815-578 and 1830-186 into a common housing with built-in ethernet switch.</i>	

80 Series Mounting Accessories

1803-150 Surface Mount Recess Kit	430.00
1814-165 Flush Mount Kit Stainless Steel	738.00
1814-152 Surface Mount Ring for Flush Units	316.00

90 Series Mounting Accessories

1814-180 Stainless Steel Hood (10 ga) ¹	580.00
1814-185 Black Hood (10 ga)	286.00
1814-200 Flush Kit (Rough-in box + trim ring).....	842.00
<i>1 – Recommended for corrosive environments such as coastal areas.</i>	

Accessories

1506-081 Secondary Keypad surface mount.....	596.00
1506-091 Secondary Keypad flush mount.....	1028.00
1720-080 LED Light Kit	596.00
1804-193 External Speaker	570.00
1801-008 Backup Battery 12-Volt .8 Ah	124.00
2600-584 Heater Kit.....	226.00
1812-145 CCTV Color Camera	1374.00
1807-012 Handset Kit (surface mount only)	566.00
1830-310 TTY Add-on Factory Installed	420.00
1830-315 TTY Add-on Kit	468.00

Expansion Options

2358-010 Tracker Expansion Board.....	690.00
2351-080 Sgl Box ¹ (1 board max)	936.00
2351-085 Sgl Box ¹ + 1470-080 900 MHz RF Module ..	1364.00
2351-082 QUAD Box ¹ Pre-wired (4 boards max)	1782.00
<i>1 – Includes one (1) 2358-010 board and 16V, 40 VA transformer.</i>	

Expansion Option Wireless Kits

2333-080 Base Board Kit ¹ 900 MHz.....	834.00
1470-080 Expansion Board Kit ² 900 MHz.....	494.00
2332-080 Dual channel repeater 900 MHz	774.00
<i>1 – One (1) base board kit is installed in the 1833 controller.</i>	
<i>2 – Expansion board kit(s) are installed on each 2358 tracker board.</i>	
1514-079 900 MHz antenna extension kit	80.72
8064-046 Coax cable extension 13-ft (3.9m)	70.22
1514-028 Disk antenna 900 MHz	45.06
1514-019 Six inch (152mm) antenna 900 MHz	45.06
1514-140 Wireless range test kit 900 MHz	1058.00

Elevator Control

2348-040 ¹ Elevator control board + hardware.....	2968.00
2348-080 ² Lockable enclosure	3846.00
2348-081 ³ Lockable enclosure large	4198.00
<i>1 – Includes board and mounting hardware.</i>	
<i>2 – Includes one (1) 2348-010 board. Room for two (2) boards' total.</i>	
<i>3 – Includes one (1) 2340-010 board. Room for four (4) boards' total.</i>	

1837 Telephone Entry / Access Control System


Residential, Commercial

1837 80 Series


- Separate surface and flush mount designs
- Surface mount includes black hood
- Optional surface mount trim ring
- Optional stainless steel flush mount kit
- Optional stainless steel wall mount trim ring for flush units

1837 90 Series


- Larger cabinet
- One design for surface, flush or wall mounting
- Dual locks, double weather seal
- Space for card reader, IP camera, TCP-IP adapter
- Optional 10 ga. hood, stainless steel or black
- Optional stainless steel flush mount kit



80 Series - Surface Mount



80 Series - Flush Mount



90 Series - Surface, Flush or Wall Mount

Model ¹	Phone Numbers	Directory	Entry Codes ²	Device Codes ³	Relays	Auxiliary Inputs ⁴	Expansion ⁵	DKS Cloud Programming ⁶	Elevator Control	Transaction Buffer
1837	3000	8-Line Electronic	3000	8000	3	2	48 Max	Yes	Yes	8000

1. 90 Series internal card reader mounting will accommodate the following card readers only: 1815-302 (DK Prox), 1815-380 (HID), 1815-215 (ID-Teck).
2. Entry codes are four (4) digits only and are not the same as device codes. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
3. Device codes refer to any five (5) digit 26-bit wiegand device used to access an entry point, such as cards, transmitters or PINs (Personal Identification Number). Five (5) digit device codes can also be used on the system keypad.
4. 1837 has two 26-bit wiegand inputs.
5. Up to 48 additional entry points can be controlled via card readers, AVID tag readers, RF receivers or digital keypads using wired tracker expansion boards. This is reduced to 24 if using wireless expansion.
6. DKS Cloud is included with connection service subscription plans. Programming with a dedicated PC is available using the Remote Account Manager software - available for free download at doorking.com.

1837 Telephone Entry / Access Control System**Residential, Commercial****1837 Telephone Entry / Access Control System**

1837-080 80 Series Surface Mount	7390.00
1837-084 80 Series Flush Mount	7390.00
1837-090 90 Series Surface, Flush or Wall Mount	7390.00

Service Connection Options

1800-080 Cellular Voice + Data ¹	1822.00
2334-080 VoIP – TCP/IP Control Box ^{3,5}	848.00
1815-578 VoIP Adapter ^{2,4}	200.00
1830-186 Plug & Play ^{3,4} (Plug & Play)	306.00
1830-185 Network Adapter (Manual Setup)	306.00
<i>1 – DKS Cellular subscription required. See Section D1.</i>	
<i>2 – DKS VoIP subscription required. See Section D1.</i>	
<i>3 – DKS VoIP or Data over IP subscription required. See Section D1.</i>	
<i>4 – 1815-578 is required for voice, 1830-186 or 1830-185 is required for data</i>	
<i>5 – Combines the 1815-578 and 1830-186 into a common housing with built-in ethernet switch.</i>	

80 Series Mounting Accessories

1803-150 Surface Mount Recess Kit	430.00
1814-165 Flush Mount Kit Stainless Steel	738.00
1814-152 Surface Mount Ring for Flush Units	316.00

90 Series Mounting Accessories

1814-180 Stainless Steel Hood (10 ga) ¹	580.00
1814-185 Black Hood (10 ga)	286.00
1814-200 Flush Kit (Rough-in box + trim ring)	842.00
<i>1 – Recommended for corrosive environments such as coastal areas.</i>	

Accessories

1506-081 Secondary Keypad surface mount	596.00
1506-091 Secondary Keypad flush mount	1028.00
1720-080 LED Light Kit	596.00
1804-193 External Speaker	570.00
1801-008 Backup Battery 12-Volt .8 Ah	124.00
2600-584 Heater Kit	226.00
1812-145 CCTV Color Camera	1374.00
1807-012 Handset Kit (surface mount only)	566.00
1830-310 TTY Add-on Factory Installed	420.00
1830-315 TTY Add-on Kit	468.00

Expansion Options

2358-010 Tracker Expansion Board	690.00
2351-080 Sgl Box ¹ (1 board max)	936.00
2351-085 Sgl Box ¹ + 1470-080 900 MHz RF Module ..	1364.00
2351-082 QUAD Box ¹ Pre-wired (4 boards max)	1782.00
<i>1 – Includes one (1) 2358-010 board and 16V, 40 VA transformer.</i>	

Expansion Option Wireless Kits

2333-080 Base Board Kit ¹ 900 MHz	834.00
1470-080 Expansion Board Kit ² 900 MHz	494.00
2332-080 Dual channel repeater 900 MHz	774.00
<i>1 – One (1) base board kit is installed in the 1833 controller.</i>	
<i>2 – Expansion board kit(s) are installed on each 2358 tracker board.</i>	

1514-079 900 MHz antenna extension kit	80.72
8064-046 Coax cable extension 13-ft (3.9m)	70.22
1514-028 Disk antenna 900 MHz	45.06
1514-019 Six inch (152mm) antenna 900 MHz	45.06
1514-140 Wireless range test kit 900 MHz	1058.00

Elevator Control

2348-040 ¹ Elevator control board + hardware	2968.00
2348-080 ² Lockable enclosure	3846.00
2348-081 ³ Lockable enclosure large	4198.00
<i>1 – Includes board and mounting hardware.</i>	
<i>2 – Includes one (1) 2348-010 board. Room for two (2) boards' total.</i>	
<i>3 – Includes one (1) 2340-010 board. Room for four (4) boards' total.</i>	


1838 Access Controller

Commercial



1838

- Stores up to 3000 user names
- Programmable directory codes
- Built-in clock/calendar
- Voice communication capability
- Optional plug-in programming display
- Two (2) built-in relays control relays
- Two (2) 26-bit wiegand inputs
- Expandable to control up to 24 entrances
- 31 security (permission) levels
- 32 holiday schedules
- True anti-pass back features

Access Controller



Call Stations



Model	User Names	Directory	Entry Codes ¹	Device Codes ²	Relays	Auxiliary Inputs ³	Expansion ⁴	DKS Cloud Programming ⁵	Elevator Control	Transaction Buffer
1838	3000	N / A	3000	8000	2	2	48 Max	Yes	Yes	8000

1. Entry codes are four (4) digits only and are not the same as device codes. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
2. Device codes refer to any five (5) digit 26-bit wiegand device used to access an entry point, such as cards, transmitters or PINs (Personal Identification Number). Five (5) digit device codes can also be used on the system keypad.
3. 1838 has two 26-bit wiegand inputs.
4. Up to 48 additional entry points can be controlled via card readers, AVID tag readers, RF receivers or digital keypads using wired tracker expansion boards. This is reduced to 24 if using wireless expansion.
5. DKS Cloud is included with connection service subscription plans. Programming with a dedicated PC is available using the Remote Account Manager software - available for free download at doorking.com.

1838 Access Controller

Commercial

1838 Access Controller

1838-081 Surface Mount	2680.00
------------------------------	---------

Service Connection Options

1800-080 Cellular Voice + Data ¹	1822.00
---	---------

2334-080 VoIP – TCP/IP Control Box ^{3,5}	848.00
---	--------

1815-578 VoIP Adapter ^{2,4}	200.00
--	--------

1830-186 Plug & Play ^{3,4} (Plug & Play)	306.00
---	--------

1830-185 Network Adapter (Manual Setup)	306.00
---	--------

1 – DKS Cellular subscription required. See Section D1.

2 – DKS VoIP subscription required. See Section D1.

3 – DKS VoIP or Data over IP subscription required. See Section D1.

4 – 1815-578 is required for voice, 1830-186 or 1830-185 is required for data

5 – Combines the 1815-578 and 1830-186 into a common housing with built-in ethernet switch.

Call Stations^{1, 2}

1838-120 Call station w/keypad	1164.00
--------------------------------------	---------

1838-121 Call Station w/ID Tech card reader	942.00
---	--------

1838-122 Call station w/AWID card reader	920.00
--	--------

1838-123 Call station w/HID card reader	1242.00
---	---------

1838-124 Call station w/DK Prox card reader	806.00
---	--------

1838-134 Call Station w/DK ProxPlus card reader	806.00
---	--------

1494-010 Microphone combiner ³	96.90
---	-------

1 – Provides voice communication via telephone communication.

2 – Requires active telephone line.

3 – Use if two call stations will share the same telephone line.

Accessories

1838-220 1 x 20 LCD Programming Display	1164.00
---	---------

1506-081 Secondary Keypad surface mount	596.00
---	--------

1506-091 Secondary Keypad flush mount	1028.00
---	---------

1801-008 Backup Battery 12-Volt .8 Ah	124.00
---	--------

Expansion Options

2358-010 Tracker Expansion Board	690.00
--	--------

2351-080 Sgl Box ¹ (1 board max)	936.00
---	--------

2351-085 Sgl Box ¹ + 1470-080 900 MHz RF Module ..	1364.00
---	---------

2351-082 QUAD Box ¹ Pre-wired (4 boards max)	1782.00
---	---------

1 – Includes one (1) 2358-010 board and 16V, 40 VA transformer.

Expansion Option Wireless Kits

2333-080 Base Board Kit ¹ 900 MHz	834.00
--	--------

1470-080 Expansion Board Kit ² 900 MHz	494.00
---	--------

2332-080 Dual channel repeater 900 MHz	774.00
--	--------

1 – One (1) base board kit is installed in the 1833 controller.

2 – Expansion board kit(s) are installed on each 2358 tracker board.

1514-079 900 MHz antenna extension kit	80.72
--	-------

8064-046 Coax cable extension 13-ft (3.9m)	70.22
--	-------

1514-028 Disk antenna 900 MHz	45.06
-------------------------------------	-------

1514-019 Six inch (152mm) antenna 900 MHz	45.06
---	-------

1514-140 Wireless range test kit 900 MHz	1058.00
--	---------

Elevator Control

2348-040 ¹ Elevator control board + hardware	2968.00
---	---------

2348-080 ² Lockable enclosure	3846.00
--	---------

2348-081 ³ Lockable enclosure large	4198.00
--	---------

1 – Includes board and mounting hardware.

2 – Includes one (1) 2348-010 board. Room for two (2) boards' total.


3 – Includes one (1) 2340-010 board. Room for four (4) boards' total.

1838 Access Plus Controller

Residential, Commercial

1838 AP

- Stores up to 100 user names
- Programmable directory codes
- Built-in clock/calendar
- Voice communication capability
- Optional plug-in programming display
- Control up to 8 entry points
- IP Addressable
- PC Programmable
- 2-Digit directory codes
- 20-digit dialing
- Includes 16 VAC power transformer



Model	Phone Numbers	Directory Names	Entry Codes ¹	Device Codes ²	Relays	Auxiliary Inputs ³	Expansion ⁴	PC Programmable ⁵	Temporary Codes	Holiday Schedules
1838 AP	27	N/A	50	100	2	2	6 Max	Yes	10	Yes

1. Entry codes are four (4) digits only and are not the same as device codes. Entry codes grant access when entered on the entry system keypad (or secondary keypad) only.
2. Device codes refer to any five (5) digit RS-485 device used to access an entry point, such as cards, transmitters or PINs (Personal Identification Number). Five (5) digit device codes can also be used on the system keypad.
3. 1838 AP uses a standard RS-485 data input.
4. Six (6) additional entry points can be controlled via RS-485 card readers, AVID tag readers, RF receivers or digital keypads.
5. AP Programming software available for free download at doorking.com.

1838 Access Plus Controller**Residential, Commercial****1838 Access Plus Controller**

1838-095 Surface Mount 2432.00

Service Connection Options1800-081 Cellular Voice + Data¹ 1822.002334-081 VoIP – TCP/IP Control Box² 848.001815-578 VoIP Adapter² 200.00*1 – DKS Cellular subscription required. See Section D1.**2 – DKS VoIP or Data subscription required. See Section D1.***1838 Access Plus Expansion Options**

2354-010 Conversion Board 244.00

1815-235 Conversion Board w/Enclosure 542.00

Converts 26-bit Wiegand to RS-485. Requires 12-16 VDC power.

1812-018 12-VDC, 1A Transformer 65.92

1200-080 Transformer Box 314.00

1816-083 Intercom Phone Expansion 1534.00

*The 1816-083 expands the “No Phone Line” telephone intercom interface on Access Plus systems from a single phone line up to 11 phone lines. The system can be further expanded to interface with up to a maximum of 23 phone lines.***RS-485 Card Readers (ACCESS PLUS ONLY)**

1815-337 DK ProxPlus Secure 614.00

1815-332 DK Prox Reader 596.00

1815-232 ID Tech Reader 678.00

1815-233 AWID Reader 710.00

1815-234 HID Reader 1230.00

RS-485 Keypads (ACCESS PLUS ONLY)

1513-081 Surface Mount 730.00

1513-082 Flush Mount 904.00

RS-485 RF Controls (ACCESS PLUS ONLY)

8053-080 MicroPlus Receiver 290.00

2100 Series Video Entry Systems


Residential

2108 / 2112


- Control up to three entry points
- Broadcast calling up to four phone numbers
- Internet or cellular connection
- Program from a laptop, tablet or smartphone
- All programming saved in the DKS Cloud

App


- DKS 2112 Resident app
- App available on App Store and Google Play
- Initiate video stream at any time from the app
- Activate door or gate from the app
- Check door/ gate status




2112 Surface Mount




2112 Surface Mount Curved




2112 Flush Mount



2108 Surface Mount



Cellular Kit External - use with
2108 / 2112 Surface Mount



Cellular Kit Internal - use with
2112 Surface Mount Curved Only

Model ¹	Phone Numbers ²	Directory Codes ³	Entry Codes ⁴	Relays	Auxiliary Inputs	IP Camera	Cloud Programming ⁵	Do Not Call Schedule	Hold Open Schedules
2108 2112	40	10	500	3	0	Yes	Yes	Yes	Yes

1. The 2108 / 2112 must have an internet connection (wired or cellular) to operate. If using cellular for the 2108 surface mount, 2112 surface mount or 2112 flush mount, an external cellular kit is required (2112-152 or 2112-153). Standard residential package subscription is required (see Section C1, pages 10-11 for subscription rates). 2108 has a built-in paper directory for up to 10 residents.
2. Up to four (4) phone numbers per directory code.
3. 10 directory codes are available, meaning the 2100 series can be used for up to 10 residents. Directory codes can be set for one (1) to five (5) digits in length.
4. Entry codes can be set to four (4) digits or five (5) digits in length.
5. Program from a laptop, tablet, or smartphone.

2100 Series Video Entry System

Residential

2108 Video Entry System

2108-090 Surface Mount¹ 2100.00

1 – If using cellular, external cellular kit is required.

2112 Video Entry System

2112-081 Surface Mount¹ 2230.00

2112-082 Surface Mount Curved 2230.00

2112-083 Flush Mount¹ 2740.00

1 – If using cellular, external cellular kit is required.

Subscription Fees

Standard Residential Package monthly subscription fee is required for 2100 series systems to operate. See Section D1.

Subscription fee includes:

- VoIP for Voice Calling
- Video Calling (requires the DKS 2112 app on your smartphone)
- DKS Cloud database for programming and system management
- On command video monitoring (from your smartphone)
- Relay (door/gate) status (open – closed – held open)
- On command relay control (open – close – hold open)
- Scheduled relay control
- Entry code functions

Cellular Kits Internal

2112-150 Cellular Kit Internal T-Mobile^{1,2} 258.00

2112-151 Cellular Kit Internal AT&T^{1,2,3} 258.00

1 – Cellular add-on subscription required. See Section D1.

2 – Use with 2112 surface mount curved only.

3 – AT&T cellular service requires Minimum Build 32 (check your 2108 / 2112 online account event log – type “build” in the search bar).

Cellular Kits External

2112-152 Cellular Kit External T-Mobile^{1,2} 428.00

2112-153 Cellular Kit External AT&T^{1,2,3} 428.00

1 – Cellular add-on subscription required. See Section D1.

2 – Use with flush or surface mount units.

3 – AT&T cellular service requires Minimum Build 32 (check your 2108 / 2112 online account event log – type “build” in the search bar).

Upgrade Kits⁴

2112-581 Kit 1812 to 2112 Surface/Flush Mount^{1,2} 2030.00

2112-582 Kit 1812 to 2112 Surface Mount Curved³ 2030.00

1 – Convert 1812 -081, 1812-089, 1812-090, 1812-092, 1812-097, 1812-098, 1812-099 to 2112.

2 – If using cellular, external cellular kit will be required.

3 – Convert 1812- 095, 1812-096 to 2112.

4 – The 2112 system does not have any expansion capabilities. Be aware of this if converting an 1812 Access Plus system to a 2112 system.

Transformer / Power Supply


1804-060 Transformer 16 VAC, 20 VA¹ 70.26

1200-080 Transformer Box 314.00

1 – Transformer is included with the 2108 / 2112.

Connection Options

Cellular, TCP/IP Network, VoIP



DKS Cloud is included with connection service subscription plans which allow programming from a laptop, tablet or smartphone. Programming with a dedicated PC is also available using the Remote Account Manager software - available for free download at doorking.com.

Cellular¹

1800-080 Voice + Data.....	1822.00
1800-081 Voice + Data (AP models only).....	1822.00

1. Cellular subscription required. See Section D1.

VoIP – TCP/IP Control box¹

2334-080 VoIP – TCP/IP Control Box ²	848.00
2334-081 VoIP – TCP/IP Control Box ³	848.00

1. DKS VoIP or Data subscription required. See Section D1.

2. Use with 1830 Series systems only.

IMPORTANT! The 1830 circuit board MUST be Revision Z or higher, otherwise this product will not work.

3. Use with Access Plus systems only.

Accessories¹

1514-014 Long Range Antenna 4GLTE.....	178.00
--	--------

1 – 1800-080 and 1800-081 only.

TCP/IP Network Adapters

1830-185 (Manual setup).....	306.00
1830-186 ¹ (Plug & Play)	306.00

1. DKS VoIP or Data over IP subscription required. See Section D1.

VoIP Adapter

1815-578 ¹	200.00
-----------------------------	--------

1. DKS VoIP subscription required. See Section D1.


Programming Only (No Voice) Connection Options¹

1508-055 RS232 to RS422 Conversion Kit	1698.00
1815-037 USB to RS232 Adapter.....	244.00
1818-040 RS232 Connecting Cable 6-ft (1.8m)	64.58

1 – These options are used with a dedicated PC connected directly to the entry system control board. Programming with a dedicated PC is available using the Remote Account Manager software - available for free download at doorking.com.

Model 2348


Elevator Control



Elevator Control Board	
2348-040	2968.00
• Includes mounting hardware.	
Enclosures ¹	
2348-080	3846.00
• Maximum two (2) 2348 boards.	
2348-081	4198.00
• Maximum four (4) 2348 boards.	
<i>1. Includes one (1) 2348 control board and power transformer.</i>	

Expansion Boards

Tracker Expansion Boards



Tracker Expansion Board

2358-010 690.00

Enclosures

2351-080 936.00

- Includes one (1) 2358-010 board and 16V, 20 VA transformer.

2351-085 1364.00

- Includes one (1) 2358-010 board, 1470-080 RF Module, 900 MHz and 16V, 20 VA transformer.

2351-082 1782.00


- Includes one (1) 2358-010 board and 16V, 40 VA transformer.
- Can hold a maximum four (4) 2358-010 boards.
- Pre-wired.

Wireless Kits

Tracker Expansion Board Wireless Kits

900 MHz

IMPORTANT! 900 MHz wireless expansion can only be used with 2358 expansion boards, REV N or higher.




Baseboard Kit 2333-080 900 MHz834.00 - Plugs into the 1830 series control board. - Includes antenna kit and vandal resistant disk antenna. Expansion Board Kit 1470-080 900 MHz494.00 - Plugs into the 2358 expansion board. - Includes 6-inch and vandal resistant disk antenna. Dual Channel Repeater 2332-080 900 MHz774.00 - Extends the range when multiple 1470 or 1489 kits are in use.	Accessories 1514-079 Antenna Kit 900 MHz 80.72 - Includes 6-inch antenna, mounting bracket and 13-foot cable. 8064-046 Extension Cable 68.18 Antennas 1514-019 6-inch Antenna 900 MHz 45.06 1514-028 Disk Antenna 900 MHz 45.06 Field Range Test Kit 1514-140 900 MHz 1058.00 - Use to verify a good wireless connection between base and remote stations.
---	---


Mounting Kits

Telephone Entry System Mounting Kits

Use with 1803, 1810 and 1833, 1834, 1835, 1837 - 80 Series only



Use with 1834, 1835, 1837 - 90 Series only



80 Series Only

Surface Mount Recess Kit - Black

1803-150430.00

- Use with surface mount 1803, 1810, 1833, 1834, 1835 and 1837 80 Series only.

Flush Kit Stainless Steel

1814-165738.00

- Use with flush mount 1803, 1810, 1833, 1834, 1835 and 1837 80 Series only.

Surface Mount Adapter for Flush Units

1814-152316.00

- Allows a flush mount unit to be mounted directly to a flat surface. Indoor use only.
- Use with flush mount 1803, 1810, 1833, 1834, 1835 and 1837 80 Series only.

90 Series Only

Hood – Stainless Steel

1814-180..... 580.00

- Use with 1834-090, 1835-090 and 1837-090 systems only.

Hood – Black

1814-185..... 286.00

- Use with 1834-090, 1835-090 and 1837-090 systems only.



Flush Kit Stainless Steel (rough-in box + trim ring)

1814-200..... 842.00

- Use with 1834-090, 1835-090 and 1837-090 systems only.

Model 1720


Telephone Entry System LED Light Kit



LED Light Kit - Long	
1720-080	596.00
Use with surface mount 1803, 1810, 1833, 1834, 1835 and 1837 systems.	
LED Light Kit - Short	
1720-081	582.00
Use with add-on directory.	

General Purpose Utility Enclosures

Telephone Entry System Accessories



General purpose enclosures have no power receptacles or terminal strips, carry no warranty and are not listed.

0102-080 Small lockable metal enclosure	248.00
0102-081 Large lockable metal enclosure	820.00
0102-082 Medium lockable metal enclosure	506.00
0102-083 Small lockable plastic enclosure	262.00
0102-084 Medium lockable plastic enclosure	286.00

Part Number	Height	Width	Depth	Material	Lockable
0102-080	9.00 (229mm)	6.00 (152mm)	3.63 (92mm)	Metal	Yes
0102-081	24.38 (619mm)	14.25 (362mm)	4.00 (102mm)	Metal	Yes
0102-082	10.25 (260mm)	12.25 (311mm)	4.25 (108mm)	Metal	Yes
0102-083	9.88 (251mm)	6.63 (168mm)	4.00 (102mm)	Plastic	Yes
0102-084	12.25 (311mm)	11.50 (292mm)	6.00 (152mm)	Plastic	Yes

Blank Page

Accessories

Handset Kits, Isolation Transformers, Miscellaneous, CCTV Camera Kits

Handset Conversion Kit

1807-012566.00

Handset, adapter, hanger and speaker cover

Replacement Handset

1807-006436.00

Isolation Transformers

1830-140 16V (363ma)104.00

Use with 1802, 1803, 1808, 1810, 1812 Plus & AP Systems

1830-141 24V (500ma)104.00

Use with 1812 Classic

1830-142 16V (727ma)104.00

Use with 1834, 1835, 1837

Miscellaneous

1506-081 Secondary Keypad surface mount596.00

1506-091 Secondary Keypad flush mount1028.00

1801-008 Backup Battery 12-Volt .8 AH124.00

1804-193 External Speaker570.00

Use in high noise areas

2600-584 Heater Kit226.00

2600-588 Heater Kit364.00

2600-582 LCD Heater Kit88.58

1816-070 Line Sense Relay71.04

Key Lock Sets (Lock + 2 Keys)

4001-052 Lock #16002 (Access Systems).....53.64

4001-055 Lock #16001 (Gate Operators).....53.64

4001-035 Lock #16120.....53.64

4001-038 Lock #16121.....53.64

4001-039 Lock #16122.....53.64

4001-041 Lock #16123.....53.64

4001-042 Lock #16124.....53.64

4001-043 Lock #16125.....53.64

4001-044 Lock #16126.....53.64

4001-045 Lock #16127.....53.64

4001-046 Lock #16128.....53.64

4001-047 Lock #16129.....53.64

4001-048 Lock #16130.....53.64

CCTV Camera Kit – High Resolution

1812-145..... 1374.00

High resolution color camera kit (camera, mounting bracket, wire harness, power supply)

Use this camera with the following models:

1802-082, 1802-089, 1802-090, 1802-091, 1802-092

1803-080, 1803-084, 1803-090, 1803-092

1808-081, 1808-082, 1808-083, 1808-084, 1808-085

1810-084, 1810-090, 1810-096

1812-088, 1812-093, 1812-094

1833-080, 1833-084

1834-084, 1834-089

1835-084, 1835-089

1837-080, 1837-084, 1837-089

1838-120, 1838-021, 1838-122, 1838-123, 1838-124

CCTV Camera Kit – High Resolution

1812-147..... 1374.00

High resolution color camera kit (camera, mounting bracket, wire harness, power supply)

Use this camera with the following models:

1810-080, 1810-088, 1810-095

1812-081, 1812-087, 1812-089, 1812-090, 1812-091, 1812-092, 1812-095, 1812-096, 1812-097, 1812-098, 1812-099

1815-247, 1815-248, 1815-249, 1815-250, 1815-251

1834-080, 1834-090

1835-080, 1835-090

1837-090

Video Adapter

1812-039..... 726.00

Converts coax to twisted pair for wire runs of up to 3000-ft (B/W) or 1600-ft (color), two required

Replacement Components

Electronic Components

Circuit Boards

1800-009	1436.00
Use with 1800-081 only (Access Plus Cellular)	
1800-010	1436.00
Use with 1800-080 only (Voice + Data Cellular)	
1862-010	1356.00
Use with 1802, 1802-EPD, 1803, 1808, 1810, 1819	
1863-010	968.00
Use with all "P" series lobby panels	
1871-010	1978.00
Use with 1812 Classic only	
1971-010	1978.00
Use with 1812 Plus only	
1885-010	2420.00
Use with 1816 and 1820 only	
1833-010	2420.00
Use with 1833 only	
1834-010	2584.00
Use with 1834-080 and 1834-084 only	
1834-009	2584.00
Use with 1834-089 and 1834-090 only	
1835-010	2968.00
Use with 1835-080 and 1835-084 only	
1835-009	2968.00
Use with 1835-089 and 1835-090 only	
1837-010	2420.00
Use with 1837 only	
1838-010	2458.00
Use with 1838 only	
1970-010	2298.00
Use with 1802 AP, 1808 AP, 1810 AP, 1812 AP, 1838 AP	

Miscellaneous

1998-020	142.00
Replacement microphone kit	
1998-010	142.00
Replacement microphone board	
1997-190	16.98
Microphone wire harness for 1998-010 only	
1804-290	38.74
5-watt speaker (square)	
1817-190	54.86
Oval speaker	

Keypads

1895-017	190.00
Keypad no letters	
1895-019	176.00
Keypad 10-pin	
1804-038	33.88
Ribbon cable for 1895-016 & 1895-017	
1804-155	210.00
Keypad (no letters) & ribbon cable	
1804-156	210.00
Keypad (with letters) & ribbon cable	
1895-032	202.00
Keypad, green back lighted	
1895-060	436.00
Lighted keypad-green, A-Z-CALL button retrofit kit	
1804-158	214.00
Lighted keypad-green, retrofit kit	

LCD Displays

1891-010 Single-Line 20 Character	1128.00
Use with 1834, 1835	
1896-012 Eight-Line 20 Character	1128.00
Use with 1837 only	
1890-010 Single-Line 8 Character	372.00
Use with 1802, 1803 and 1810	
1902-010 Single-Line 16 Character	540.00
Use with 1802 EPD only	

LED Light Kits

1804-700	83.96
Use with 1810 surface mount	
1804-701	32.30
Use with 1802	
1804-702	58.10
Use with 1808, 1834, 1835 surface mount	
1804-703	58.10
Use with 1710 directory	
1804-704	32.30
Use with 1812	
1804-707	58.10
Use with 1810 flush mount	

Blank Page